Misty 2.5 (Model #10025)

⚠ CAUTION **⚠**

NEVER DISMANTLE ANY OF THIS PRODUCT AFTER IT HAS BEEN PRESSURIZED. DO NOT OVERPRESSURIZE. BOTH ACTIONS CAN RESULT IN SERIOUS INJURY!

Instructions for Use:

Step 1: Unscrew Cap and Fill

- Twist the cap counter dockwise to separate and remove from the bottle. (See Figure 1)
- Add water to the bottle up to the "Fill Line" (See Figure 2)

Note: Overfilling the bottle will restrict the mister from pressurizing to its maximum potential.

Replace the cap onto the bottle and gently tighten

Note: Applying too much force when screwing on the cap can damage the unit. Be sure not to over-rotate the cap.

Step 2: Pressurize

- Hold the bottle firmly with one hand, and gently grab the colored base of the bottle with the other hand.
- Pump the mister 10 15 times by gently sliding the base in and out of the bottle.
 It is normal to feel resistance as you pressurize the mister. (See Figure 3)

Note: Use short quick pumps to add pressure. Damage can occur if the shaft is pumped with too much force.

Note: The base will not fit comfortably inside the bottle if too much pressure is applied. (See Depressurization Instructions below)

Step 3: Mist

Press the "Mist" button as needed to enjoy the ultrafine and refreshing mist (See Figure 4)

Care and Cleaning:

- Using water with impurities can severely shorten the life of the nozzle and the mister. Only use the cleanest water with the product (purified or distilled)
- NEVER open the cap after you have applied pressure to the bottle or pumped it at all. Depressurize unit first.

 Depressurize (hold the bottle upside-down with the nozzle facing the ground and press the 'Mist' button for 5-10 second. Air and some water will come out and you should be able to safely remove the cap.)
- To clean, rinse bottle with soap and water; Air dry bottle upside down and be sure no sitting water is in the tubing.





Figure 1

Fi gu re 2





Figure 3

Figure 4