

Misty 8oz and 16oz

(Model 11008 and 11016)



CAUTION

NEVER dismantle this product after it has been pressurized. DO NOT overpressurize. Both actions can result in serious injury!

Cleaning and Care:

- Using water with impurities can severely shorten the life of the nozzle and the mister. Only use the cleanest water with the product (purified or distilled)
- **NEVER** open the cap after you have applied pressure to the bottle or pumped it at all. Depressurize unit first. (See below)
- To clean, rinse bottle with soap and water; Air dry bottle upside-down and be sure no sitting water is in the tubing.(DO NOT put the mister in the dishwasher).
- **DO NOT** put the mister in the freezer (with or without water inside of bottle.)

Step 1: Filling the Bottle

- Twist cap counter clockwise to separate and remove from the bottle.
- Rinse the inside of the bottle with water before the 1st use.
- Locate the "Fill Line" on the outside of the bottle; add purified or distilled water to the container up to the Fill Line.
- Replace the cap onto the bottle and close tightly.
Note: Overfilling the bottle will restrict the mister from pressurizing to its maximum potential. Be sure there is at least 2 inches of space from the Fill Line to the rim that remains empty.

Step 2: Pressurizing the Bottle

- Hold the bottle firmly with one hand, and the *Pump Handle* with your other hand.
- Pump the Mister 10-15 times by sliding the *Pump Shaft* in and out of the bottle. It is normal to feel resistance as the mister builds pressure.
Note: It is not necessary for the mister to be fully pressurized to achieve the optimal cooling effect. The Pressure Gauge will be your guide in determining when and how much pressure needs to be added to the bottle. NEVER pump the bottle where the gauge reads past the 2nd Red Dot.

Step 3: Mist

- Pull back on the *Valve Lever* moving it away from the *Misting Nozzle* to start and enjoy the ultrafine and refreshing mist!
- Apply more pressure to the bottle as needed to maintain your desired level of mist.

Depressurize Instructions:

Depressurize your mister before refilling or before removing the cap for ANY reason while the unit is pressurized.

- Hold the mister upside-down (*Misting Nozzle* pointing towards the ground)
- Turn the *Valve Lever* away from the *Misting Nozzle* to begin depressurizing.
Note: It is normal for mist to spray for the first few seconds
- Continue depressurizing until you can no longer hear air escaping from the nozzle.