

# Cooling Cap

Model # 17001

**Note:** *Misty Mate recommends that you pre-wash (with warm water and soap) and allow the unit to dry completely before the first use in order to prevent the material from bleeding.*

## *Directions:*

- Submerge the Cooling Cap in a bowl of cold water for 3- 5 minutes in order to ensure maximum absorbency.
- Remove the Cooling Cap from the bowl and lightly squeeze out any excess water – do not twist or wring. Distribute the cooling crystals evenly throughout.
- Place the Cooling Cap on your head. Tie ends loosely behind your head for a comfortable fit.

Note: For prolonged use, repeat steps every 1- 2 hours.

**CAUTION:** IN THE EVENT THE PRODUCT TEARS OR BREAKS,  
PLEASE DISPOSE. DO NOT INGEST.

Cover: 100% Cotton

Fill: Methyl Methacrylate, Washing Soda, Acrylamide (polyacrylamide), NN – Methy-lene – Bis – Acrylamide, Potassium Persulfate, Hydrosulfite of Sodium

DESIGNED IN THE USA – MANUFACTURED IN CHINA

[WWW.MISTYMATE.COM](http://WWW.MISTYMATE.COM)